




Explozie piese de schimb

Motopompa de presiune

BTA-MPP80



E-01 Engine assy

No.	Part No.	English name	QTY
1	33580-00014-00	BOLT,M6×60	1
2	20021-00004-00	COVER COMP.HEAD	1
3	33048-00028-00	GASKET,HEAD COVER	1
4	34024-00002-00	CLIP,FUEL PIPE	1
5	34023-00020-00	TUBE,BREATHER	1
6	30121-00034-00	NUT,VALVE ADJUSTING	2
7	30134-00005-00	ROCKER SHAFT	2
8	34019-00005-00	ROCKER ARM	2
9	30110-00033-00	BOLT VALVE	2
10	/		/

11	34016-00007-00	RETAINER, VALVE SPRING	1
12	33141-00022-00	ROTATOR, VALVE	1
13	34016-00007-00	RETAINER, VALVE SPRING	1
14	34015-00004-00	SPRING, VALVE	2
15	34007-00001-00	OIL SEAL	1
16	34016-00008-00	RETAINER, VALVE BOTTOM	2
17	34017-00008-00	PLATE, PUSH ROD GUIDE	1
18	30101-00506-00	BOLT, M10×80	4
19	20027-00010-00	SPARK PLUG	1
20	30110-00028-00	BOLT, STUD, EXHAUST	2
21	33048-00095-00	WASHER, MUFFLER	1
22	20202-00338-00	MUFFLER ASSY	1
23	30125-00003-00	NUT M8	2
24	34021-00001-00	WIND COVER, DOWN	1
25	30101-00070-00	BOLT M6×12	1
26	20023-00061-00	CYLINDER HEAD COMP	1
27	30110-00022-00	BOLT, STUD, INTAKE	2
28	33048-00053-00	GASKET, INTAKE	1
29	34012-00014-00	INSULATOR, CARBURE TOR	1
30	33048-00078-00	GASKET, CARBURETOR	1
31	20024-00100-00	CARBURETOR	4
32	33048-00082-00	GASKET, AIR CLEANER	1
33	30101-00070-00	NUT, FLANGE	1
34	30125-00002-00	CLIP, TUBE	2
35	20025-00043-00	AIR CLEANER ASSY	1
36	/	BASE COMP, AIR CLEANER	1
37	/	ELEMENT ASSY, AIR CLEANER	1
38	/	NUT, BUTTERFLY	1
39	/	COVER, AIR CLEANER	1
40	33048-00034-00	GASKET, HEAD COVER	1
41	34006-00007-00	DOWEL PIN	2
42	34013-00034-00	VALVE, EXHAUST	1
43	34013-00080-00	VALVE, INTAKE	1

44	34020-00010-00	PUSH ROD	2
45	34008-00006-00	LIFTER, VALVE	2
46	20084-00009-00	RING SET, PISTON	1
47	34004-00016-00	PISTON	1
48	34006-00015-00	PIN, PISTON	1
49	30150-00023-00	CLIP, PISTON PIN	2
50	20008-00008-00	CONNECTING ROD ASSY	1
51	30101-00514-00	BOLT M12×16	2
52	30136-00080-00	WASHER	2
53	34011-00019-00	CRANKCASE	1
54	34026-00005-00	SHAFT, GOVERNOR	1
55	30136-00095-00	WASHER	1
56	34007-00002-00	OIL SEAL	1
57	34006-00017-00	PIN, LOCK	1
58	30101-00342-00	BOLT M6×16	2
59	33247-00010-00	ENGINE OIL SENSOR	1
60	34024-00004-00		1
61	33246-00002-00	OIL ALARM	1
62	30101-00070-00	BOLT, M6×12	13
63	30141-00116-00	BEARING	1
64	20012-00017-00	CAMSHAFT, ASSY	1
65	/	/	
66	34033-00001-00	BALANCE SHAFT	1
67	20013-00004-00	GOVERNOR GEAR KIT	1
68	20011-00049-00	CRANKSHAFT ASSY	1
69	30141-00116-00	BEARING	1
70	30141-00112-00	BEARING	2
71	33048-00063-00	GASKET, CRANKCASE COVER	1
72	33129-00015-00	CRANKCASE COVER	1
73	20026-00019-00	OIL CAP ASSY	1
74	20026-00005-00	OIL CAP ASSY	1
75	34006-00001-00	DOWEL PIN	2
76	30101-00370-00	BOLT	7
77	34007-00012-00	OIL SEAL	1
78	34007-00012-00	OIL SEAL	1
79	30101-00408-00	BOLT	13
80	20028-00029-00	WIRE, ENGINE SWITCH	1
81	20051-00018-00	FLYWHEEL COMP	1
82	33155-00042-00	FAN COOLING	1
83	34022-00008-00	PULLEY, STARTER	1
84	30125-00035-00	NUT SPECIAL	1

85	20010-00069-05	RECOIL STARTER COMP	1
86	/	WIND GUIDER,RECOIL	1
87	/	COVER COMP	1
88	/	BOLT,FLANGE	3
89	30101-00070-00	BOLT M6×12	1
90	31026-00057-00	ENGINE SWITCH	1
91	34023-00004-00	FUEL PIPE	0.235m
92	34024-00002-00	CLIP,FUEL PIPE	1
93	33036-00044-00	RUBBER FIXED BLOCK	1
94	30125-00003-00	NUT,FLANGE	2
95	30101-00098-00	BOLT,FLANGE	2
96	20130-00028-02	FUEL TANK ASSY	1
97	/	/	1
98	34026-00008-00	ROD,GOVERNOR	1
99	34015-00020-00	SPRING,CABLE RETURN	1
100	34015-00010-00	SPRING,THROTTLE RETURN	1
101	34025-00007-00	HANDLE,SPEED CONTROL	1
102	20022-00013-00	SPEED CONTROL,ASSY	1
103	30101-00070-00	BOLT	2