

No	零件名称	Name	Qty
1	M16防松螺母	NUT M16	2
2	Ø16 平垫	WASHER Ø16	4
3	轮子	WHEEL	2
4	滤网	OIL FILTER	1
5	螺母ZG1 1/2	INLET OIL HOSE NUT ZG1 1/2	1
6	接头 3/8-M18x1.5	CONNECTOR 3/8-M18X1.5	1
7	齿轮泵	GEAR PUMP	1
8	平垫8	WASHER Ø8	16
9	弹垫8	SPRING WASHER Ø8	8
10	内六角圆柱头螺钉M8x85	SCREW M8X85	2
11	钢丝抱箍	HOOP	4
12	吸油管	INLET OIL HOSE	1
13	齿轮泵进油管接头	INLET OIL HOSE CONNECTOR	1
14	M10x30外六角螺栓	BOLT M10X30	4
15	平垫10	WASHER Ø10	21
16	电机	MOTOR	1
17	十字槽盘头螺钉M4x55	SCREW M4X55	2
18	开关	SWITCH	1
19	高压油管C	HIGH PRESSURE HOSE C	1
20	控制阀回油管接头	CONTROL VALVE CONNECTOR	1
21	控制阀	CONTROL VALVE	1
22	1/2-M18x1.5角通	1/2-M18x1.5 CONNECTOR	2
23	R销Ø1.6x38	R PIN Ø1.6x38	4
24	开口销Ø1.6x10	COTTER PIN Ø1.6x10	1
25	销轴 5x25B	ROLL PIN 5X25B	1
26	连接杆	CONNECTING LEVER	1
27	组合密封垫圈16	COMBINATION SEALING WASHER 16	1
28	放油螺塞	OIL DRAIN PLUG	1
29	操纵手柄管（左）	CONTROL HANDLE(LEFT)	1
30	手柄套 22	HANDLE COVER 22	2
31	扶手	HANDLE BAR	1
32	M8x16 六角螺栓	BOLT M8X16	4
33	M10x65六角螺栓	BOLT M10X65	1
34	高压油管A	HIGH PRESSURE HOSE A	1
35	高压油管B	HIGH PRESSURE HOSE B	1
36	油缸总成	CYLINDER SET	1
37	M10防松螺母	NUT M10	17
38	10弹垫	SPRING WASHER Ø10	4
39	名牌座	PROTECTION COVER	1

40	M6x12法兰面螺钉	SCREW M6X12	4
41	护板	PROTECTION PLATE	1
42	操纵手柄管（右）	CONTROL HANDLE(RIGHT)	1
43	M8防松螺母	NUT M8	8
44	刀组件	WEDGE	1
45	M10x45盘头内六角螺栓	BOLT M10X45	6
46	衬板	WEDGE SPACER	2
47	轨道平板(左)	WEDGE PLATE(LEFT)	1
48	联动板	CONNECTING PLATE	2
49	M10x35外六角螺栓	BOLT M10X35	4
50	回油管	MEDIUM PRESSURE OIL HOSE	1
51	M4防松螺母	NUT M4	2
52	25管帽	PROTECTION PIPE COVER	2
53	档管	PROTECTION PIPE	2
54	M8x20六角螺栓	BOLT M8X20	8
55	机架	MAIN BODY	1
56	接头 1/2-M18x1.5	CONNECTOR 1/2-M18X1.5	1
57	内六角螺栓M8x40	SCREW M8X40	2
58	轨道平板(右)	WEDGE PLATE(RIGHT)	1
59	M6防松螺母	NUT M6	6
60	Ø6平垫	WASHER Ø6	2
61	小滑块(左)	SMALL SLIDER(LEFT)	1
62	小滑块(右)	SMALL SLIDER(RIGHT)	1
63	小衬板	SMALL PLATE	2
64	圆木钉板	LOG FIXING PLATE	1
65	M6x30沉头螺栓	BOLT M6X30	4

canceled
canceled
canceled
canceled
canceled
canceled
canceled
canceled