



BT1500-A  
code:10005-00701-00



factory code with part NO.	PART. NUMBER	CODE	DESCRIPCION	OBSERVATIONS
10005-00701-00-01	1	Exploded View	Decoration case	For High Pressure Washer SC1400
10005-00701-00-02	2	Exploded View	Top cover	For High Pressure Washer SC1400
10005-00701-00-03	3	Exploded View	Handle	For High Pressure Washer SC1400

10005-00701-00-04	4	Exploded View	Pump & motot	For High Pressure Washer SC1400
10005-00701-00-05	5	Exploded View	Base cover	For High Pressure Washer SC1400
10005-00701-00-06	6	Exploded View	Right cable reel baffle	For High Pressure Washer SC1400
10005-00701-00-07	7	Exploded View	left cable reel baffle	For High Pressure Washer SC1400
10005-00701-00-08	8	Exploded View	cable reel	For High Pressure Washer SC1400
10005-00701-00-09	9	Exploded View	left wheel cover	For High Pressure Washer SC1400
10005-00701-00-10	10	Exploded View	Right wheel cover	For High Pressure Washer SC1400
10005-00701-00-11	11	Exploded View	Switch box cover	For High Pressure Washer SC1400
10005-00701-00-12	12	Exploded View	Switch	For High Pressure Washer SC1400
10005-00701-00-13	13	Exploded View	Switch box	For High Pressure Washer SC1400
10005-00701-00-14	14	Exploded View	switch joint	For High Pressure Washer SC1400
10005-00701-00-15	15	Exploded View	switch knob	For High Pressure Washer SC1400
10005-00701-00-16	16	Exploded View	Spray gun	For High Pressure Washer SC1400
10005-00701-00-17	17	Exploded View	gun lance	For High Pressure Washer SC1400
10005-00701-00-18	18	Exploded View	spray nozzle	For High Pressure Washer SC1400
10005-00701-00-19	19	Exploded View	HPC connector	For High Pressure Washer SC1400
10005-00701-00-20	20	Exploded View	Water inlet joint	For High Pressure Washer SC1400
10005-00701-00-21	21	Exploded View	high pressure tube	For High Pressure Washer SC1400
10005-00701-00-22	22	Exploded View	gun hook	For High Pressure Washer SC1400

pump & alternator  
BT1500-A 10005-  
00701-00-04



factory code with part NO.	PART. NUMBER	CODE	DESCRIPCION	OBSERVATIONS
10005-00701-00-04-01	1	PUMP & Motor list Exploded View	Screw	For High Pressure Washer SC1400
10005-00701-00-04-02	2	PUMP & Motor list Exploded View	spring gasket	For High Pressure Washer SC1400
10005-00701-00-04-03	3	PUMP & Motor list Exploded View	flat gasket	For High Pressure Washer SC1400

10005-00701-00-04-04	4	PUMP & Motor list Exploded View	Pump cover	For High Pressure Washer SC1400
10005-00701-00-04-05	5	PUMP & Motor list Exploded View	seal	For High Pressure Washer SC1400
10005-00701-00-04-06	6	PUMP & Motor list Exploded View	General valve spring	For High Pressure Washer SC1400
10005-00701-00-04-07	7	PUMP & Motor list Exploded View	Valve core	For High Pressure Washer SC1400
10005-00701-00-04-08	8	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-09	9	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-10	10	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-11	11	PUMP & Motor list Exploded View	General valve seat	For High Pressure Washer SC1400
10005-00701-00-04-12	12	PUMP & Motor list Exploded View	Valve cover	For High Pressure Washer SC1400
10005-00701-00-04-13	13	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-14	14	PUMP & Motor list Exploded View	Valve plates	For High Pressure Washer SC1400
10005-00701-00-04-15	15	PUMP & Motor list Exploded View	valve spring	For High Pressure Washer SC1400
10005-00701-00-04-16	16	PUMP & Motor list Exploded View	valve seat	For High Pressure Washer SC1400
10005-00701-00-04-17	17	PUMP & Motor list Exploded View	pump	For High Pressure Washer SC1400
10005-00701-00-04-18	18	PUMP & Motor list Exploded View	Y water seal	For High Pressure Washer SC1400
10005-00701-00-04-19	19	PUMP & Motor list Exploded View	Screw	For High Pressure Washer SC1400
10005-00701-00-04-20	20	PUMP & Motor list Exploded View	spring gasket	For High Pressure Washer SC1400
10005-00701-00-04-21	21	PUMP & Motor list Exploded View	flat gasket	For High Pressure Washer SC1400
10005-00701-00-04-22	22	PUMP & Motor list Exploded View	guide ring	For High Pressure Washer SC1400
10005-00701-00-04-23	23	PUMP & Motor list Exploded View	Oil seal	For High Pressure Washer SC1400
10005-00701-00-04-24	24	PUMP & Motor list Exploded View	Plunger frame	For High Pressure Washer SC1400
10005-00701-00-04-25	25	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-26	26	PUMP & Motor list Exploded View	Plunger spring	For High Pressure Washer SC1400
10005-00701-00-04-27	27	PUMP & Motor list Exploded View	Plunger	For High Pressure Washer SC1400
10005-00701-00-04-28	28	PUMP & Motor list Exploded View	Plunger spring seat	For High Pressure Washer SC1400
10005-00701-00-04-29	29	PUMP & Motor list Exploded View	Screw	For High Pressure Washer SC1400
10005-00701-00-04-30	30	PUMP & Motor list Exploded View	spring gasket	For High Pressure Washer SC1400
10005-00701-00-04-31	31	PUMP & Motor list Exploded View	flat gasket	For High Pressure Washer SC1400
10005-00701-00-04-32	32	PUMP & Motor list Exploded View	motor	For High Pressure Washer SC1400
10005-00701-00-04-33	33	PUMP & Motor list Exploded View	Bearing	For High Pressure Washer SC1400
10005-00701-00-04-34	34	PUMP & Motor list Exploded View	Gearwheel	For High Pressure Washer SC1400

10005-00701-00-04-35	35	PUMP & Motor list Exploded View	transmission shaft	For High Pressure Washer SC1400
10005-00701-00-04-36	36	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-37	37	PUMP & Motor list Exploded View	Cylinder gasket	For High Pressure Washer SC1400
10005-00701-00-04-38	38	PUMP & Motor list Exploded View	Cylinder	For High Pressure Washer SC1400
10005-00701-00-04-39	39	PUMP & Motor list Exploded View	oil seal ring	For High Pressure Washer SC1400
10005-00701-00-04-40	40	PUMP & Motor list Exploded View	Bearing	For High Pressure Washer SC1400
10005-00701-00-04-41	41	PUMP & Motor list Exploded View	Cam	For High Pressure Washer SC1400
10005-00701-00-04-42	42	PUMP & Motor list Exploded View	flat gasket	For High Pressure Washer SC1400
10005-00701-00-04-43	43	PUMP & Motor list Exploded View	spring gasket	For High Pressure Washer SC1400
10005-00701-00-04-44	44	PUMP & Motor list Exploded View	Screw	For High Pressure Washer SC1400
10005-00701-00-04-45	45	PUMP & Motor list Exploded View	Thrust bearing	For High Pressure Washer SC1400
10005-00701-00-04-46	46	PUMP & Motor list Exploded View	Screw	For High Pressure Washer SC1400
10005-00701-00-04-47	47	PUMP & Motor list Exploded View	Rear cover	For High Pressure Washer SC1400
10005-00701-00-04-48	48	PUMP & Motor list Exploded View	Micro switch	For High Pressure Washer SC1400
10005-00701-00-04-49	49	PUMP & Motor list Exploded View	push arm	For High Pressure Washer SC1400
10005-00701-00-04-50	50	PUMP & Motor list Exploded View	overflow valve plug	For High Pressure Washer SC1400
10005-00701-00-04-51	51	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-52	52	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-53	53	PUMP & Motor list Exploded View	Retaining ring	For High Pressure Washer SC1400
10005-00701-00-04-54	54	PUMP & Motor list Exploded View	overflow valve spring	For High Pressure Washer SC1400
10005-00701-00-04-55	55	PUMP & Motor list Exploded View	push rod	For High Pressure Washer SC1400
10005-00701-00-04-56	56	PUMP & Motor list Exploded View	push rod seat	For High Pressure Washer SC1400
10005-00701-00-04-57	57	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-58	58	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-59	59	PUMP & Motor list Exploded View	push rod seat cover	For High Pressure Washer SC1400
10005-00701-00-04-60	60	PUMP & Motor list Exploded View	O ring	For High Pressure Washer SC1400
10005-00701-00-04-61	61	PUMP & Motor list Exploded View	top cover	For High Pressure Washer SC1400
10005-00701-00-04-62	62	PUMP & Motor list Exploded View	inner wire	For High Pressure Washer SC1400
10005-00701-00-04-63	63	PUMP & Motor list Exploded View	Connector A	For High Pressure Washer SC1400
10005-00701-00-04-64	64	PUMP & Motor list Exploded View	Connector A gasket	For High Pressure Washer SC1400
10005-00701-00-04-65	65	PUMP & Motor list Exploded View	filter	For High Pressure Washer SC1400

10005-00701-00-04-66


66

PUMP & Motor list Exploded View

screw

For High Pressure Washer SC1400

BT1900-B  
code:10005-00702-00




factory code with part NO.	PART. NUMBER	CODE	DESCRIPCION	OBSERVATIONS
10005-00702-00-01	1	Exploded View	Front casing insert	For High Pressure Washer SC1800
10005-00702-00-02	2	Exploded View	Decoration case	For High Pressure Washer SC1800

10005-00702-00-03	3	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-04	4	Exploded View	Pump & Motor	For High Pressure Washer SC1800
10005-00702-00-05	5	Exploded View	Back cover	For High Pressure Washer SC1800
10005-00702-00-06	6	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-07	7	Exploded View	Built-in soap bottle	For High Pressure Washer SC1800
10005-00702-00-08	8	Exploded View	Built-in soap bottle lid	For High Pressure Washer SC1800
10005-00702-00-09	9	Exploded View	Power cable bracket	For High Pressure Washer SC1800
10005-00702-00-10	10	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-11	11	Exploded View	Switch knob	For High Pressure Washer SC1800
10005-00702-00-12	12	Exploded View	handle bracket shaft	For High Pressure Washer SC1800
10005-00702-00-13	13	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-14	14	Exploded View	switch box cover	For High Pressure Washer SC1800
10005-00702-00-15	15	Exploded View	Rock switch	For High Pressure Washer SC1800
10005-00702-00-16	16	Exploded View	switch box cover	For High Pressure Washer SC1800
10005-00702-00-17	17	Exploded View	Power cord	For High Pressure Washer SC1800
10005-00702-00-18	18	Exploded View	wheel	For High Pressure Washer SC1800
10005-00702-00-19	19	Exploded View	Caster plate	For High Pressure Washer SC1800
10005-00702-00-20	20	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-21	21	Exploded View	wheel cover	For High Pressure Washer SC1800
10005-00702-00-22	22	Exploded View	long handle	For High Pressure Washer SC1800
10005-00702-00-23	23	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-24	24	Exploded View	Pressure plate	For High Pressure Washer SC1800
10005-00702-00-25	25	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-26	26	Exploded View	Reel right shell	For High Pressure Washer SC1800
10005-00702-00-27	27	Exploded View	Handle bracket shaft	For High Pressure Washer SC1800
10005-00702-00-28	28	Exploded View	Reel handle	For High Pressure Washer SC1800
10005-00702-00-29	29	Exploded View	Handle bracket shaft	For High Pressure Washer SC1800
10005-00702-00-30	30	Exploded View	Reel handle shaft	For High Pressure Washer SC1800
10005-00702-00-31	31	Exploded View	Tap screws	For High Pressure Washer SC1800
10005-00702-00-32	32	Exploded View	Coil plate	For High Pressure Washer SC1800
10005-00702-00-33	33	Exploded View	High pressure tube pressure block	For High Pressure Washer SC1800

10005-00702-00-34	34	Exploded View	Two way pressure plate	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-35	35	Exploded View	Tap screws	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-36	36	Exploded View	Tap screws	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-37	37	Exploded View	Cable clamp	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-38	38	Exploded View	Pipette	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-39	39	Exploded View	U Type pin	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-40	40	Exploded View	U Type pin short	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-41	41	Exploded View	high pressure connecting pipe	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-42	42	Exploded View	Spray gun	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-43	43	Exploded View	gun lance	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-44	44	Exploded View	spray nozzle	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-45	45	Exploded View	HPC connector	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-46	46	Exploded View	Water inlet joint	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-47	47	Exploded View	high pressure tube	For High Pressure Washer <a href="#">SC1800</a>
10005-00702-00-48	48	Exploded View	gun hook	For High Pressure Washer <a href="#">SC1800</a>

pump & alternator  
for BT1900-B  
10005-00702-00-04




factory code with part NO.	PART. NUMBER	CODE	DESCRIPCION	OBSERVATIONS
10005-00702-00-04-01	1	PUMP & Motor list Explode	Bearing	For High Pressure Washer SC1800
10005-00702-00-04-02	2	PUMP & Motor list Explode	Great Gear	For High Pressure Washer SC1800
10005-00702-00-04-03	3	PUMP & Motor list Explode	Transmission shaft	For High Pressure Washer SC1800
10005-00702-00-04-04	4	PUMP & Motor list Explode	Skeleton oil seal	For High Pressure Washer SC1800

10005-00702-00-04-05	5	PUMP & Motor list Explode	Bearing	For High Pressure Washer SC1800
10005-00702-00-04-06	6	PUMP & Motor list Explode	Cam	For High Pressure Washer SC1800
10005-00702-00-04-07	7	PUMP & Motor list Explode	Bearing	For High Pressure Washer SC1800
10005-00702-00-04-08	8	PUMP & Motor list Explode	Plunger spring seat	For High Pressure Washer SC1800
10005-00702-00-04-09	9	PUMP & Motor list Explode	Plunger	For High Pressure Washer SC1800
10005-00702-00-04-10	10	PUMP & Motor list Explode	Plunger spring	For High Pressure Washer SC1800
10005-00702-00-04-11	11	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-12	12	PUMP & Motor list Explode	Plunger frame	For High Pressure Washer SC1800
10005-00702-00-04-13	13	PUMP & Motor list Explode	Skeleton oil seal	For High Pressure Washer SC1800
10005-00702-00-04-14	14	PUMP & Motor list Explode	Plunger guide ring	For High Pressure Washer SC1800
10005-00702-00-04-15	15	PUMP & Motor list Explode	Y ring	For High Pressure Washer SC1800
10005-00702-00-04-16	16	PUMP & Motor list Explode	Pump	For High Pressure Washer SC1800
10005-00702-00-04-17	17	PUMP & Motor list Explode	Valve seat	For High Pressure Washer SC1800
10005-00702-00-04-18	18	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-19	19	PUMP & Motor list Explode	Valve core	For High Pressure Washer SC1800
10005-00702-00-04-20	20	PUMP & Motor list Explode	Check valve spring	For High Pressure Washer SC1800
10005-00702-00-04-21	21	PUMP & Motor list Explode	Valve cover	For High Pressure Washer SC1800
10005-00702-00-04-22	22	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-23	23	PUMP & Motor list Explode	Valve plate	For High Pressure Washer SC1800
10005-00702-00-04-24	24	PUMP & Motor list Explode	Valve seat	For High Pressure Washer SC1800
10005-00702-00-04-25	25	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-26	26	PUMP & Motor list Explode	Hexagon socket head screw	For High Pressure Washer SC1800
10005-00702-00-04-27	27	PUMP & Motor list Explode	Seal ring	For High Pressure Washer SC1800
10005-00702-00-04-28	28	PUMP & Motor list Explode	Pump	For High Pressure Washer SC1800
10005-00702-00-04-29	29	PUMP & Motor list Explode	Spring	For High Pressure Washer SC1800
10005-00702-00-04-30	30	PUMP & Motor list Explode	Steel Ball $\Phi 4$	For High Pressure Washer SC1800
10005-00702-00-04-31	31	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-32	32	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-33	33	PUMP & Motor list Explode	Suction fluid connector	For High Pressure Washer SC1800
10005-00702-00-04-34	34	PUMP & Motor list Explode	Spring washer	For High Pressure Washer SC1800
10005-00702-00-04-35	35	PUMP & Motor list Explode	Hexagon socket head screw	For High Pressure Washer SC1800

10005-00702-00-04-36	36	PUMP & Motor list Explode	Suction fluid nozzle	For High Pressure Washer SC1800
10005-00702-00-04-37	37	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-38	38	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-39	39	PUMP & Motor list Explode	Putting seat cover	For High Pressure Washer SC1800
10005-00702-00-04-40	40	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-41	41	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-42	42	PUMP & Motor list Explode	Putting seat	For High Pressure Washer SC1800
10005-00702-00-04-43	43	PUMP & Motor list Explode	External spring	For High Pressure Washer SC1800
10005-00702-00-04-44	44	PUMP & Motor list Explode	Putter	For High Pressure Washer SC1800
10005-00702-00-04-45	45	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-46	46	PUMP & Motor list Explode	Mesh gasket	For High Pressure Washer SC1800
10005-00702-00-04-47	47	PUMP & Motor list Explode	O ring	For High Pressure Washer SC1800
10005-00702-00-04-48	48	PUMP & Motor list Explode	Hexagon Screw plug	For High Pressure Washer SC1800
10005-00702-00-04-49	49	PUMP & Motor list Explode	Under cover	For High Pressure Washer SC1800
10005-00702-00-04-50	50	PUMP & Motor list Explode	Push arm	For High Pressure Washer SC1800
10005-00702-00-04-51	51	PUMP & Motor list Explode	Micro switch	For High Pressure Washer SC1800
10005-00702-00-04-52	52	PUMP & Motor list Explode	Top cover	For High Pressure Washer SC1800
10005-00702-00-04-54	54	PUMP & Motor list Explode	Cylinder	For High Pressure Washer SC1800
10005-00702-00-04-55	55	PUMP & Motor list Explode	Motor 9640	For High Pressure Washer SC1800
10005-00702-00-04-56	56	PUMP & Motor list Explode	Sealing plug	For High Pressure Washer SC1800
10005-00702-00-04-57	57	PUMP & Motor list Explode	Flat pad	For High Pressure Washer SC1800
10005-00702-00-04-58	58	PUMP & Motor list Explode	Hexagon socket head screw	For High Pressure Washer SC1800
10005-00702-00-04-59	59	PUMP & Motor list Explode	Inside Wire	For High Pressure Washer SC1800
10005-00702-00-04-60	60	PUMP & Motor list Explode	Inside Spring	For High Pressure Washer SC1800
10005-00702-00-04-61	61	PUMP & Motor list Explode	Plug spring	For High Pressure Washer SC1800
10005-00702-00-04-62	62	PUMP & Motor list Explode	Jacket	For High Pressure Washer SC1800
10005-00702-00-04-63	63	PUMP & Motor list Explode	Wire Jacket	For High Pressure Washer SC1800
10005-00702-00-04-64	64	PUMP & Motor list Explode	Capacitance	For High Pressure Washer SC1800
10005-00702-00-04-65	65	PUMP & Motor list Explode	Motor wind cover	For High Pressure Washer SC1800

BT2350-B  
code:10005-00703-00



factory code with part NO.	PART. NUMBER	CODE	DESCRIPCION	OBSERVATIONS
10005-00703-00-01	1	Exploded View	Front casing insert	For High Pressure Washer SC2200
10005-00703-00-02	2	Exploded View	Decoration case	For High Pressure Washer SC2200
10005-00703-00-03	3	Exploded View	Tap screws	For High Pressure Washer SC2200

10005-00703-00-04	4	Exploded View	Pump & Motor	For High Pressure Washer SC2200
10005-00703-00-05	5	Exploded View	Back cover	For High Pressure Washer SC2200
10005-00703-00-06	6	Exploded View	Tap screws	For High Pressure Washer SC2200
10005-00703-00-07	7	Exploded View	Built-in soap bottle	For High Pressure Washer SC2200
10005-00703-00-08	8	Exploded View	Built-in soap bottle lid	For High Pressure Washer SC2200
10005-00703-00-09	9	Exploded View	Power cable bracket	For High Pressure Washer SC2200
10005-00703-00-10	10	Exploded View	Tap screws	For High Pressure Washer SC2200
10005-00703-00-11	11	Exploded View	Switch knob	For High Pressure Washer SC2200
10005-00703-00-12	12	Exploded View	handle bracket shaft	For High Pressure Washer SC2200
10005-00703-00-13	13	Exploded View	Tap screws	For High Pressure Washer SC2200
10005-00703-00-14	14	Exploded View	switch box cover	For High Pressure Washer SC2200
10005-00703-00-15	15	Exploded View	Rock switch	For High Pressure Washer SC2200
10005-00703-00-16	16	Exploded View	switch box cover	For High Pressure Washer SC2200
10005-00703-00-17	17	Exploded View	Power cord	For High Pressure Washer SC2200
10005-00703-00-18	18	Exploded View	wheel	For High Pressure Washer SC2200
10005-00703-00-19	19	Exploded View	Caster plate	For High Pressure Washer SC2200
10005-00703-00-20	20	Exploded View	Tap screws	For High Pressure Washer SC2200
10005-00703-00-21	21	Exploded View	wheel cover	For High Pressure Washer SC2200
10005-00703-00-22	22	Exploded View	long handle	For High Pressure Washer SC2200
10005-00703-00-23	23	Exploded View	Tap screws	For High Pressure Washer SC2200
10005-00703-00-24	24	Exploded View	Pressure plate	For High Pressure Washer SC2200
10005-00703-00-25	25	Exploded View	Tap screws	For High Pressure Washer SC2200
10005-00703-00-26	26	Exploded View	Reel right shell	For High Pressure Washer SC2200
10005-00703-00-27	27	Exploded View	Handle bracket shaft	For High Pressure Washer SC2200
10005-00703-00-28	28	Exploded View	Reel handle	For High Pressure Washer SC2200
10005-00703-00-29	29	Exploded View	Handle bracket shaft	For High Pressure Washer SC2200
10005-00703-00-30	30	Exploded View	Reel handle shaft	For High Pressure Washer SC2200
10005-00703-00-31	31	Exploded View	Tap screws	For High Pressure Washer SC2200
10005-00703-00-32	32	Exploded View	Coil plate	For High Pressure Washer SC2200
10005-00703-00-33	33	Exploded View	High pressure tube pressure block	For High Pressure Washer SC2200
10005-00703-00-34	34	Exploded View	Two way pressure plate	For High Pressure Washer SC2200

10005-00703-00-35	35	Exploded View	Tap screws	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-36	36	Exploded View	Tap screws	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-37	37	Exploded View	Cable clamp	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-38	38	Exploded View	Pipette	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-39	39	Exploded View	U Type pin	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-40	40	Exploded View	U Type pin short	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-41	41	Exploded View	high pressure connecting pipe	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-42	42	Exploded View	Spray gun	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-43	43	Exploded View	gun lance	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-44	44	Exploded View	spray nozzle	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-45	45	Exploded View	HPC connector	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-46	46	Exploded View	Water inlet joint	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-47	47	Exploded View	high pressure tube	For High Pressure Washer <a href="#">SC2200</a>
10005-00703-00-48	48	Exploded View	gun hook	For High Pressure Washer <a href="#">SC2200</a>

pump & alternator  
for BT2350-B  
10005-00703-00-04



factory code with part NO.	PART. NUMBER	CODE	DESCRIPCION	OBSERVATIONS
10005-00703-00-04-01	1	PUMP & Motor list Explode	Bearing	For High Pressure Washer SC2000
10005-00703-00-04-02	2	PUMP & Motor list Explode	Great Gear	For High Pressure Washer SC2200
10005-00703-00-04-03	3	PUMP & Motor list Explode	Transmission shaft	For High Pressure Washer SC2200

10005-00703-00-04-04	4	PUMP & Motor list Explode	Skeleton oil seal	For High Pressure Washer SC2200
10005-00703-00-04-05	5	PUMP & Motor list Explode	Bearing	For High Pressure Washer SC2200
10005-00703-00-04-06	6	PUMP & Motor list Explode	Cam	For High Pressure Washer SC2200
10005-00703-00-04-07	7	PUMP & Motor list Explode	Bearing	For High Pressure Washer SC2200
10005-00703-00-04-08	8	PUMP & Motor list Explode	Plunger spring seat	For High Pressure Washer SC2200
10005-00703-00-04-09	9	PUMP & Motor list Explode	Plunger	For High Pressure Washer SC2200
10005-00703-00-04-10	10	PUMP & Motor list Explode	Plunger spring	For High Pressure Washer SC2200
10005-00703-00-04-11	11	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-12	12	PUMP & Motor list Explode	Plunger frame	For High Pressure Washer SC2200
10005-00703-00-04-13	13	PUMP & Motor list Explode	Skeleton oil seal	For High Pressure Washer SC2200
10005-00703-00-04-14	14	PUMP & Motor list Explode	Plunger guide ring	For High Pressure Washer SC2200
10005-00703-00-04-15	15	PUMP & Motor list Explode	Y ring	For High Pressure Washer SC2200
10005-00703-00-04-16	16	PUMP & Motor list Explode	Pump	For High Pressure Washer SC2200
10005-00703-00-04-17	17	PUMP & Motor list Explode	Valve seat	For High Pressure Washer SC2200
10005-00703-00-04-18	18	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-19	19	PUMP & Motor list Explode	Valve core	For High Pressure Washer SC2200
10005-00703-00-04-20	20	PUMP & Motor list Explode	Check valve spring	For High Pressure Washer SC2200
10005-00703-00-04-21	21	PUMP & Motor list Explode	Valve cover	For High Pressure Washer SC2200
10005-00703-00-04-22	22	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-23	23	PUMP & Motor list Explode	Valve plate	For High Pressure Washer SC2200
10005-00703-00-04-24	24	PUMP & Motor list Explode	Valve seat	For High Pressure Washer SC2200
10005-00703-00-04-25	25	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-26	26	PUMP & Motor list Explode	Hexagon socket head screw	For High Pressure Washer SC2200
10005-00703-00-04-27	27	PUMP & Motor list Explode	Seal ring	For High Pressure Washer SC2200
10005-00703-00-04-28	28	PUMP & Motor list Explode	Pump	For High Pressure Washer SC2200
10005-00703-00-04-29	29	PUMP & Motor list Explode	Spring	For High Pressure Washer SC2200
10005-00703-00-04-30	30	PUMP & Motor list Explode	Steel Ball $\Phi 4$	For High Pressure Washer SC2200
10005-00703-00-04-31	31	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-32	32	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-33	33	PUMP & Motor list Explode	Suction fluid connector	For High Pressure Washer SC2200
10005-00703-00-04-34	34	PUMP & Motor list Explode	Spring washer	For High Pressure Washer SC2200

10005-00703-00-04-35	35	PUMP & Motor list Explode	Hexagon socket head screw	For High Pressure Washer SC2200
10005-00703-00-04-36	36	PUMP & Motor list Explode	Suction fluid nozzle	For High Pressure Washer SC2200
10005-00703-00-04-37	37	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-38	38	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-39	39	PUMP & Motor list Explode	Putting seat cover	For High Pressure Washer SC2200
10005-00703-00-04-40	40	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-41	41	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-42	42	PUMP & Motor list Explode	Putting seat	For High Pressure Washer SC2200
10005-00703-00-04-43	43	PUMP & Motor list Explode	External spring	For High Pressure Washer SC2200
10005-00703-00-04-44	44	PUMP & Motor list Explode	Putter	For High Pressure Washer SC2200
10005-00703-00-04-45	45	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-46	46	PUMP & Motor list Explode	Mesh gasket	For High Pressure Washer SC2200
10005-00703-00-04-47	47	PUMP & Motor list Explode	O ring	For High Pressure Washer SC2200
10005-00703-00-04-48	48	PUMP & Motor list Explode	Hexagon Screw plug	For High Pressure Washer SC2200
10005-00703-00-04-49	49	PUMP & Motor list Explode	Under cover	For High Pressure Washer SC2200
10005-00703-00-04-50	50	PUMP & Motor list Explode	Push arm	For High Pressure Washer SC2200
10005-00703-00-04-51	51	PUMP & Motor list Explode	Micro switch	For High Pressure Washer SC2200
10005-00703-00-04-52	52	PUMP & Motor list Explode	Top cover	For High Pressure Washer SC2200
10005-00703-00-04-54	54	PUMP & Motor list Explode	Cylinder	For High Pressure Washer SC2200
10005-00703-00-04-55	55	PUMP & Motor list Explode	Motor 9640	For High Pressure Washer SC2200
10005-00703-00-04-56	56	PUMP & Motor list Explode	Sealing plug	For High Pressure Washer SC2200
10005-00703-00-04-57	57	PUMP & Motor list Explode	Flat pad	For High Pressure Washer SC2200
10005-00703-00-04-58	58	PUMP & Motor list Explode	Hexagon socket head screw	For High Pressure Washer SC2200
10005-00703-00-04-59	59	PUMP & Motor list Explode	Inside Wire	For High Pressure Washer SC2200
10005-00703-00-04-60	60	PUMP & Motor list Explode	Inside Spring	For High Pressure Washer SC2200
10005-00703-00-04-61	61	PUMP & Motor list Explode	Plug spring	For High Pressure Washer SC2200
10005-00703-00-04-62	62	PUMP & Motor list Explode	Jacket	For High Pressure Washer SC2200
10005-00703-00-04-63	63	PUMP & Motor list Explode	Wire Jacket	For High Pressure Washer SC2200
10005-00703-00-04-64	64	PUMP & Motor list Explode	Capacitance	For High Pressure Washer SC2200
10005-00703-00-04-65	65	PUMP & Motor list Explode	Motor wind cover	For High Pressure Washer SC2200