



NO.	DESCRIPTION	24	FIXED BOARD	38-10	STATOR
1	FRONT STAND	25	BOLT	38-11	WASHER
2	BOLT	26	BELT WHEEL	39	BOLT
3	NUT	27	BELT	40	FIXED BRACKET .
4	WASHER	28	BOLT	41	GLAND
5	BOLT	29	BOLT	42	POWER CORD&PLUG
6	CROSSBEAM	30	SUPPORT BRACKET	43	CIRCLIP
7	NUT	31	NUT	44	SMALL SHAFT
8	HANDLE	32	WASHER	45	PINION
9	BOLT	33	BIG WASHER	46	WASHER
10	NUT	34	WHEEL	47	BOLT
11	BOLT	35	OPENING PIN	48	BOLT
12	BOLT	36 A	CONTROL BOX	49	UPPER COVER OF BEARING
13	LOCKING PLATE	37	SWITCH	50	BEARING 6206Z
14	BRACKET	38	MOTOR	51	SHAFT
15	STAND TUBE	38-1	LEFT MOTOR HOLDER	52	BOTTOM COVER OF BEARING
16	CIRCLIP	38-2	RIGHT MOTOR HOLDER	53	BOLT
17	BOTTOM DRUM	38-3	BEARING 6203Z	54	BEARING 6102Z
18	GEAR RING	38-4	BOLT	55	WASHER
19	RUBBER PILLOW	38-5	FAN	56	BOLT
20	UPPER DRUM	38-6	ROTOR	57	WASHER
21	MIXING BLADE	38-7	CAPACITOR HOLDER	58	SPRING
22	BOLT	38-8	CAPACITOR	59	CONNECTION BOARD(ONLY FOR БМ-1912СБ1)
23	BOLT	38-9	NUT	60	PRESS BOARD